

# 163 | Simple Adjustable Spanner

In-wall stud spanner | No load rating published



## 01 FUNCTION

Alignment and securement device: spans the stud bay through the opposing stud punch-outs to position and secure the utility in the wall. No load rating is published.

## 02 ORDERING

| Segment | Selection | Description                       |
|---------|-----------|-----------------------------------|
| A       | A16       | 163A16: studs at 16 in. on center |
| A       | A24       | 163A24: studs at 24 in. on center |

## 03 NOTES

Adjustable spanner: a sleeve gives 1 in. of adjustment between the studs.

- Slides through opposing stud holes and locks in place.
  - Secures EMT, MC/AC and flexible conduit.
- Galvanized rod; corrosion resistant.
  - Drawings not to scale.